

This is a common motor layout that can be found in a few of our products including: • U0040 Power Sofa

2


2



- Control Buttons & Cord PART-U0040-CONTROL BUTTONS
- Motor PART-U0040S-MOTOR Transformer Motor Splitter Cord
- Transformer PART-U0040S-TRANSFORMER
- AC Power Cord PART-U0040-AC POWER CORD
- **b** Battery Storage Compartment
- Indicator Light

Troubleshooting

- + Check your breaker box for any flipped breakers
- + Unplug and re-plug all connections
- + Check cords closely to ensure that the reclining mechanism has not cut or crushed them
- + Check along cords to ensure that there are no exposed wires



U0040 Motor Layout - Interchangeable Parts

The parts for the U0040 Motor Layout can be interchanged following the guide below:

Control Buttons & Cord • PART-U0040-CONTROL BUTTONS

• PART-U0040S-MOTOR

Transformer Motor Splitter Cord

Transformer • PART-U0040S-TRANSFORMER

AC Power Cord

- PART-U0040-AC POWER CORD
- PART-271-AC POWER CORD
- PART-8550-AC POWER CORD
- PART-7850-AC POWER CORD

- PART-50570BR-AC POWER CORD
- PART-50571BR-AC POWER CORD
- PART-18585-AC POWER CORD
- PART-18597-AC POWER CORD

- PART-HP9560-AC POWER CORD
- PART-HP9960-AC POWER CORD
- PART-P9560-AC POWER CORD
- PART-P9960-AC POWER CORD