

• U0040 Power Recliner



Key

### Control Buttons & Cord PART-U0040-CONTROL BUTTONS Motor PART-U0040R-MOTOR

- Transformer Motor Cord
- Transformer PART-U0040R-TRANSFORMER
- AC Power Cord PART-U0040R-AC POWER CORD

## **Troubleshooting**

- + Check your breaker box for any flipped breakers
- + Unplug and re-plug all connections
- + Check cords closely to ensure that the reclining mechanism has not cut or crushed them
- + Check along cords to ensure that there are no exposed wires

# **U0040 Motor Layout - Interchangeable Parts**

The parts for the U0040 Motor Layout can be interchanged following the guide below:

# Control Buttons & Cord

Motor • PART-U0040R-MOTOR

### **Transformer Motor Cord** PART-U0040-MOTOR CORD

### Transformer PART-U0040R-TRANSFORMER

# **AC Power Cord**

- PART-U0040R-AC POWER CORD
- PART-271-AC POWER CORD
- PART-8550-AC POWER CORD
- PART-7850-AC POWER CORD

- PART-50570BR-AC POWER CORD
- PART-50571BR-AC POWER CORD
- PART-18585-AC POWER CORD
- PART-18597-AC POWER CORD

- PART-HP9560-AC POWER CORD
- PART-HP9960-AC POWER CORD
- PART-P9560-AC POWER CORD
- PART-P9960-AC POWER CORD