50570BR Motor Layout

This is a motor layout that can be found in the following:

- 50570BR Madeline Recliner
- 50571BR Abilene Tobacco Recliner
- 50433C Shiloh Granite Cuddler

Key

1. Control Buttons & Cord
   PART-50570BR-CONTROL BUTTONS
2. Motor
   PART-50570BR-MOTOR
3. Transformer Motor Cord
   PART-50570BR-MOTOR CORD
4. Transformer
   PART-50570BR-TRANSFORMER
5. AC Power Cord
   PART-50570BR-AC POWER CORD
6. Indicator Light
7. Battery Backup Compartment

Troubleshooting

- Check your breaker box for any flipped breakers
- Ensure the indicator light on the transformer is on
- Unplug and re-plug all connections
- Check cords closely to ensure that the reclining mechanism has not cut or crushed them
- Check along cords to ensure that there are no exposed wires

50570BR Motor Layout - Interchangeable Parts

The parts for the 50570BR Motor Layout can be interchanged following the guide below:

Control Buttons & Cord

- PART-50570BR-CONTROL BUTTONS
- PART-50571BR-CONTROL BUTTONS
- PART-50433C-CONTROL BUTTONS
- PART-50431-CONTROL BUTTONS

Motor

- PART-50570BR-MOTOR
- PART-50571BR-MOTOR
- PART-50433C-MOTOR
- PART-50431-MOTOR

Transformer Motor Cord

- PART-50570BR-MOTOR CORD
- PART-50571BR-MOTOR CORD
- PART-50433C-MOTOR CORD
- PART-50431-MOTOR CORD
- PART-18585-MOTOR CORD
- PART-18597-MOTOR CORD

Transformer

- PART-50570BR-TRANSFORMER
- PART-50571BR-TRANSFORMER
- PART-50433C-TRANSFORMER
- PART-50431-TRANSFORMER
- PART-18585-TRANSFORMER
- PART-18597-TRANSFORMER

AC Power Cord

- PART-50433C-AC POWER CORD
- PART-50431-AC POWER CORD
- PART-271-AC POWER CORD
- PART-8550-AC POWER CORD
- PART-7850-AC POWER CORD
- PART-50570BR-AC POWER CORD
- PART-50571BR-AC POWER CORD
- PART-18585-AC POWER CORD
- PART-18597-AC POWER CORD
- PART-HP9560-AC POWER CORD
- PART-HP9960-AC POWER CORD
- PART-P9560-AC POWER CORD
- PART-P9960-AC POWER CORD